


Axis Body Cam Connect G-Core/AxisBodyCamConnect



This option is used to connect an Axis Body Cam to the G-Core system. G-Core requires one G-Core AxisBodyCamConnect for each connected Body Cam Channel.

