GEUTEBRÜCK

Upgrade Kit

Windows 10 IoT LTSC / Windows 11 IoT LTSC

Contents

CONTENTS	1
BACKGROUND	1
PROCEDURE	2
Selection – LockingID vs. Entitlement	2
Copying the LockingID from the License Manager	3
Find activations in the license portal	
Logging into the license portal	4
Search for activations	4
Revocation of activated licenses	
Generate permission ticket	6
Revoke license(s) in the License Manager	7
Complete revocation in the license portal	8

Background

Licenses that authorize the use of Geutebrück software are activated for a specific piece of hardware and can only be used on that hardware. This means that if the hardware or parts of the hardware are replaced, it may be necessary to revoke the activations for that system so that the licenses can be reactivated after the hardware has been replaced.

The Geutebrück License Manager has a LockingID that uniquely identifies the system when licenses are activated. All activations performed for this system can be found in the Geutebrück license portal using this LockingID. Activations can also be searched for using the ID of an assigned entitlement that contains the license.

• The upgrade kit is used to upgrade Windows 10 to Windows 11.

The upgrade kit allows you to use the latest GEUTEBRÜCK video surveillance technology and video management software.

• After the upgrade, the Windows 10 sticker must be removed and the new Windows 11 license sticker must be affixed to the device.

General information and security Intended use



Warning: electrical energy!

Es besteht Lebensgefahr! Beachten Sie, dass Arbeiten an elektrischen Einrichtungen nur von Elektrofachkräften vorgenommen werden dürfen.



Caution!

ESD-sensitive components

Observe handling instructions!



Warning: electrical energy!

If damaged, the device must no longer be used. Disconnect the device from the power supply!



Caution!

The device must be disconnected from the power supply before carrying out any repair or maintenance work. Work on the electrical equipment may only be carried out by a qualified electrician. Only original spare parts may be used. Failure to do so may result in accidents for the user.


Procedure

Selection - LockingID vs. Entitlement

There are basically two ways to find the licenses that have been activated for the license manager of a (replacement) hardware configuration in the Geutebrück license portal in order to revoke the activation(s) there.


The first option is to search using the entitlement ID.

To do this, open the Geutebrück license manager and expand a license for which you want to revoke the activation. The Entitlement ID can be copied to the clipboard here so that it can then be pasted into the Geutebrück license portal for searching.



The Entitlement ID is a good option if a license manager only contains licenses for very few entitlements – ideally only one.


If the revocation must be carried out for an entire system – and not just for individual licenses – it is recommended to use the Locking ID instead of the Entitlement ID to search in the license portal.



The advantage of searching using the Locking ID is that this method provides an overview of all activations made for this license manager in the license portal, regardless of how many and which entitlements licenses have been activated on this system.

Copying the Locking ID from the license manager

To initiate a revocation for a system, you can first copy the Locking ID of the license manager to search for the activated licenses in the license portal.



Find activations in the license portal

Logging into the license portal

LOGIN


to access Geutebrück Licensing Portal




Forgot your Password?

Search for activations


To find the activations for the LockingID you are looking for in the license portal, you need to switch to the search tab.




Within the search, switch to "Smart Licensing Activations."




Enter the LockingID in the field provided






After entering the Locking ID and starting the search, you will see an overview of all activations that have been made for this Locking ID.




Revocation of activated licenses

Generate permission ticket

To revoke activated licenses, start the process in the license portal by selecting the "Revoke Activation" action for the activation found.



In the window that appears, you can download a permission ticket that can be used to revoke the activation in the license manager on the production system.




The permission ticket is now downloaded and saved.


Revoke license(s) in the license manager


To revoke the license in the License Manager, the generated permission ticket must be uploaded here.

To do this, select the function for deactivating licenses.




The permission ticket is now uploaded here.






After uploading the permission ticket, the file "revocation.proof" is downloaded automatically. Complete the revocation in the license portal

The downloaded file "revocation.proof" can now be uploaded to the license portal.



The license(s) are now available again in the license portal for reactivation (on the new hardware).



The revocation is complete after this step. The licenses can be reactivated on the new hardware.¹

¹ See also: Activating licenses: https://portal.geutebrueck.com/de/licensing-portal.html#c8732

GEUTEBRÜCK

Technical alterations reserved.

GEUTEBRÜCK GmbH

Im Nassen 7-9 | D-53578 Windhagen | Tel. +49 (0)2645 137-0 | Fax-999 |

E-mail: info@geutebrueck.com | Web: www.geutebrueck.com